

Painting new cedar or pine shake? For long-lasting results dip the shakes in paint prior to installation (coating both sides have proved to give extra life to shakes). Set up a drip collection system so there is less waste, as the paint drips off. Use a paintbrush about 15 minutes after you dip to brush away drips and runs on the end of the shakes.



Above: A wallpaper tray and clothes-pins a perfect drip-catch system. Set asia the edge of a large table after brushing off excess paint to free-up the drip tray.

You will need to decide if you want to dip them once or twice. It is advisable to do the first coat with a primer and the coat using 100% atex. This particular second Acrylic Latex. paint product expands contracts and therefore lasts many years in our harsh our After they are environment. dry nail the shakes up with the painted area exposed Ciap